**BODY BUILDERS INSTRUCTIONS** ..... **1**

**Section 0 – General Instructions** ..... **1**

**Section 1 – Body** ..... **2**

Conversions ..... 3

Air Conditioning ..... 3

Rear Air Conditioning ..... 3

**Section 2 – Frame** ..... **4**

Holes ..... 4

Welding ..... 4

Alterations ..... 5

**Section 3 – Front Suspension** ..... **5**

**Section 4 – Rear Suspension** ..... **5**

**Section 5 – Brakes** ..... **6**

**Section 6 – Engine** ..... **6**

**Section 7 – Transmission** ..... **9**

**Section 8 – Fuel and Exhaust** ..... **9**

Fuel Systems ..... 9

Fuel Fill ..... 9

Fuel Lines ..... 10

Fuel Tank ..... 10

Exhaust System ..... 11

**Section 9 – Steering** ..... **12**

**Section 10 – Tires** ..... **12**

**Section 12 – Electrical Battery and Battery Cables** ..... **13**

Accessory Power Supply Feeds ..... 15

**BODY BUILDERS INSTRUCTIONS – *Continued***

**Section 13 – Heating/Cooling ..... 16**

Valve Sources: ..... 16

**CHASSIS**

**M/L 11005 General Arrangement, Exterior ..... 17**

**M/L 11006 General Arrangement, Exterior ..... 18**

**M/L 110(05, 06) General Arrangement, Interior ..... 19**

**M/L 110(05, 06) General Arrangement, Interior ..... 20**

**BODY**

**M/L 110(05, 06F) Bumper, Tailgate and Dutch Door ..... 21**

**M/L 110(05, 06) Seat Mounting Hole Locations ..... 22**

**M/L 110(05, 06) Roof Rack Mounting ..... 23**

**FRAME**

Refer to Chassis – General Arrangement ..... 17-20

**AXLE/SUSPENSION**

Refer to Chassis – General Arrangement ..... 17-20

**FUEL TANK**

Refer to Chassis – General Arrangement ..... 17-20

**EXHAUST**

Refer to Chassis – General Arrangement ..... 17-20

**ELECTRICAL**

**Ordering Information ..... 24**

**NOTE:** This vehicle has two air bags – one air bag for the driver and another air bag for the right front passenger. To help prevent unwanted inflation, see GM Service Manual for Diagnostic and Service Procedures before performing any service.